
# Linear ceiling diffusers

- Type LDD and LDDL
- Installation description





TROX HESCO Schweiz AG Walderstrasse 125 Postfach 455 CH - 8630 Rüti ZH

Tel. +41 55 250 71 11 Fax +41 55 250 73 10 www.troxhesco.ch info@troxhesco.ch

# Safety instructions · Installation

### Safety instructions



### **CAUTION!**

Damage to the product due to improper handling. Check the device for damage and contamination prior to operation!

Improper handling may lead to considerable material damage of the product.

- Do not use any acid or abrasive cleaning agents.
- Adhesives from sticky tape may lead to colour damage.
- Excessive moisture may lead to colour damage and corrosion.
- Use only cleaning agents, greases and oils that are expressly specified.

#### **CAUTION!**

Risk of injury from sharp edges and corners, ridges and thin-walled sheet metal parts!

- Proceed carefully with all work.
- Wear protective gloves, safety shoes and protective helmet.



#### **WARNING!**

Danger from incorrect use. Misuse of the product may lead to dangerous situations.

The product must not be used:


- in areas subject to explosion hazards;
- in the open air without sufficient protection against weather effects;
- in atmospheres that may have a damaging and/or corrosive effect on the product due to scheduled or unscheduled chemical reactions.

### A Angular frames, individual diffusers, continous diffusers


Equipment of the angular frames with a screwless, invisible attachment system provides very simple mounting (patent pending). Clamping thickness ranges from 0 - 4 mm to 12 until 20 mm. The diffusers can thus be mounted on the duct or directly into the ceiling plates. A masonry frame is required for brick, concrete, or plaster ceilings.

If the holding spring cannot be used, the angular frame is attached to the ceiling with screws or pins. The required holes in the angular frame are provided. This type of attachment is also completely invisible after assembly of the blade grating.


#### **Ceiling plate mounting**



#### Screws or pins




#### **Duct mounting**



Flange longitudinal only

#### Masonry frame mounting




- 1 Bow only by the continuous diffusers
- 2 Recess in masonry = external dimension of LDD

#### B End-to-end joining for continuous diffusers

The units are combined into continuous diffusers according to the following pattern:

- 1. Insert end unit 1) without connecting angle A and fix in the recess (see overleaf).
- 2. Adjoin unit 2) with connecting angle A according to pattern and fix it in the recess
- 3. Insert and tighten screw B.
- **4.** Assemble all other units and the end unit according to **2.** and **3.**



#### C Blade grating


Assembly of the blade grating to the frame is also very simple. The same mounting tools are required as for the angular frame holding spring. The attachment system is invisible.


#### Mounting


- 1. Position spring hook perpendicular to blades
- 2. Place grating in angular frame
- Apply light pressure to blade grating and pivot spring hook with mounting tool behind blades
- **4.** Secure spring hook (by moving the spring hook under the blades)

#### **Dismantling**

- 1. Position spring hook perpendicular to blades
- Insert mounting tool between blade and spring hock (use one hand to press blade grating into angular frame)
- 2. Pivot mounting tool toward outside (spring hook pops out)
- 3. Position spring hook perpendicular to blades
- 4. Remove blade grating







## Plenum box

### **Application**


Plenum boxes are used, where the TROX HESCO linear ceiling diffusers cannot be built directly into the channel or connecting piece. Normally the plenum boxes are connected by flexible ducts (hoses) with the forward channel.

Plenum box with turnings inward®

Type ZK1LDD: for supply air for LDD(L)1 and LDD(L)5P Type AK1LDD: for extract air for LDD(L)1, LDD(L)6

#### **Execution**

The plenum boxes are made of galvanized steel sheet. With the supply air plenum boxes in principle a fixed resistance is inserted. Thus an even air distribution in the passage is reached.



H = 50					H = 100			H = 150			H = 200			H = 250			* H = 300		
M = 86				M = 136			M = 186				M = 236			M = 286			M = 336		
В	K	max ØD	S	K	max ØD	S	K	max ØD	S	K	max ØD	S	K	max ØD	S	K	max ØD	S	
400											1 × 249	270							
500																			
600		1 × 149 ev. 1 × 159	221		1 × 224 ev. 2 × 159	252		1 × 249	270		ev. 2 × 199	295		2 × 224	258		2 × 249	245	
750					011211100			ev. 2 × 224	283					ev. 3 × 199	280		LALIO		
900	311			381			411			411	2 × 249	270	386	3 × 224	258	386	3 × 224	258	
1000		2 × 149	001														ev. 4 × 199	280	
1250		ev. 2 × 159	221		2 × 224	252		2 × 249	270		2 × 249	270		4 × 224	258		4 × 249	245	
1500		011211100	210					ev. 3 × 224	283		ev. 4 × 224	283		ev. 3 × 249	245		5 × 249	245	
1750		3 × 149	221		3 × 199	265		3 × 249	270		4 × 249	270		5 × 249	245		5 × 249	245	
2000		ev. 3 × 159	216		ev. 3 × 224	252		ev. 4 × 224	283		4 ^ 249	270		5 x 249	245		6 × 249	245	

<sup>\*</sup> Damper type 5P is **not** available